


This is the html version of the file http://www.xantech.com/files/app_diagrams/13_RP41AV_Dia_1.pdf.
Google automatically generates html versions of documents as we crawl the web.

to operate the entire system from any room. For AC power management, refer to the Model 680-10 Installation Instructions.






Fig. 3 A typical single zone system

RP41AV